

2/4 YOR92000-0845 US2 (8728-474)





FIG.3



4/4 YDR9-20	100 - 6 101 - 6	1845	1152	06 1/07	2-4943
Instruction number	Integer Integer	Integer Integer	FloatF FloatP Adder Multiplier	FloatP.	
201 2 3 4 5 5	<i>y y</i>	<i>y</i>			/200
6 7 8 9	<i>y</i>	<i>y</i>	7 7		;
201					
	-	FIG	4		

tion Sequence		,
LoadPowerMap 1111000		
LPM 0111000		
2		
3		
LPM 0011000		
4		
5		
LPM 0010110		
6		
7		
8		
LPM 1000110		
9		
10		
•		
•		
•		
•		
FIG. 6		
HT (- 1		
1 2 6. 6		